

**FLUKE**®

Calibration

# 9118A Thermocouple Calibration Furnace

High performance furnace  
for thermocouple calibrations  
to 1200 °C



# The most flexible, accurate, and reliable horizontal calibration furnace in its class



The Fluke Calibration 9118A Thermocouple Calibration Furnace is a horizontal, open-ended tube furnace with a temperature range of 300 °C to 1200 °C. It is used for comparison calibration of noble and base-metal thermocouples by secondary high-temperature labs and instrument shops in industries such as aerospace, automotive, energy, metals, and plastics. The 9118A is the most accurate, reliable, and flexible furnace in its class, meeting the demanding requirements of high-temperature thermocouple calibration.

## Seven key features set the 9118A apart from other high-temperature calibration furnaces:

### 1 Wide temperature range spanning most high-temperature applications

Standards and guidelines such as AMS 2750 and EURAMET cg-8 require that a thermocouple be calibrated over the full temperature range in which it is used. The 9118A temperature range of 300 °C to 1200 °C covers most high-temperature applications.

### 2 Flexible configuration for calibrating many thermocouple types

The 9118A furnace can be operated with or without an isothermal block, which increases calibration workload that can be performed with a single furnace.

- **Tube furnace configuration** (without isothermal block): Base-metal thermocouples are often sheathed in formable materials such as braided fiberglass or PTFE. During calibration, they are bundled around a reference thermometer, held together with fiberglass cord or tape, and inserted into a tube furnace.
- **Isothermal block configuration:** Metal- or ceramic-sheathed thermocouples are generally constructed with noble-metal thermoelements and therefore have higher calibration accuracy requirements. The isothermal block, which accommodates up to four 6.35 mm (0.25 in) probes, improves heat transfer and temperature stability. This better equalizes the temperature between the reference probe and the unit under test (UUT), which reduces measurement uncertainty compared to calibration without a block.

The furnace configuration can be quickly changed by selecting the calibration parameters stored in the controller for the desired configuration and inserting or removing the alumina ceramic isothermal block.

**3 Best-in-class temperature stability and uniformity for calibration accuracy**

Axial and radial uniformity, as well as constant temperature stability over time, are key factors that contribute to accurate thermocouple calibrations.

To minimize axial temperature gradients, three actively controlled heater zones compensate for temperature differentials between the central zone and the front and rear zones. Type-S thermocouples, which are less susceptible to drift than other types, are used for temperature control and cutout. Axial temperature uniformity when using the isothermal block is  $\pm 0.2$  °C over a 60 mm (2.4 in) zone from full immersion at 1200 °C.

Radial (hole-to-hole) uniformity is  $\pm 0.25$  °C at 1200 °C when using the isothermal block, and  $\pm 0.5$  °C over a 14 mm (0.6 in) diameter at the center of the furnace tube without a block.

When using the isothermal block, temperature stability is  $\pm 0.1$  °C or better over the full temperature range of the furnace.

No other calibration furnace in its class comes close to this level of performance for both modes of operation.

**4 Automated setpoint control for improved lab productivity**

A proprietary programmable controller, available in nine languages (English, Chinese, French, German, Japanese, Korean, Portuguese, Spanish, and Russian), enables technicians to automate setpoint temperature control for up to eight setpoint temperatures, the temperature ramp rate, and the time duration the furnace controls at each setpoint.

Automation and data collection can be further enhanced when the Fluke 1586A Super-DAQ is connected to the 9118A furnace through the RS-232 interface. The Super-DAQ can be programmed to control the furnace's setpoint temperatures and collect data for all sensors under test once the furnace has stabilized to within parameters defined by the user. After data has been collected at the first programmed temperature, the Super-DAQ will advance the furnace to the remaining programmed temperatures, collecting data at each setpoint. Once the test has been configured and started, the technician can walk away to work on other activities.

**5 Non-metallic block helps minimize thermocouple contamination**

Calibration furnaces with metallic blocks can contaminate thermocouples, causing their accuracy to drift over time. To minimize the risk of contamination, the furnace well and isothermal block of the 9118A are constructed of non-metallic, ceramic alumina. This eliminates the need to protect the thermocouples under test with costly ceramic sleeving—reducing cost of ownership.

**6 Deep immersion depth to support most thermocouple calibrations**

Industry standards such as AMS2750 recommend calibrating thermocouples at their normal working depth of insertion. The 9118A immersion depth is 365 mm (14.4 in) when using the isothermal block and 350 mm (13.8 in) to the central point of the furnace without a block. This immersion depth is adequate for most thermocouple calibrations. The 40 mm x 700 mm (1.6 in x 27.6 in) open-ended furnace tube can also be useful when calibrating multi-junction thermocouples or when sample testing spools of thermocouple wire.

**7 Dynamic heater control and cutouts for reliability and safety**

The 9118A controls the heater power level below 100% to prevent the heater elements from overheating—improving heater reliability and lifetime. Redundant over-temperature cutouts are built into the 9118A to ensure safe operation of the furnace. These include over-temperature, chassis thermostat, fan fault, control thermocouple fault, and user programmable cutouts.



# Specifications

## General specifications

### Operating Conditions

Operating Temperature .....	5 °C to 40 °C
Storage Temperature .....	-20 °C to 70 °C
Humidity.....	80 % maximum for temperatures <31 °C, decreasing linearly to 50 % at 40 °C
Altitude .....	<2,000 m (6,562 feet)
Power Requirements .....	230 V ac (±10 %), 50/60 Hz, 20 A
Heater Power .....	4000 watts at 230 V ac

### Over-current Protection

System .....	20 A, 250 V resettable circuit breaker
Main Heater Fuse.....	F 12 A, 250 V
Zone Heater Fuse.....	F 12 A, 250 V
Computer Interface .....	RS-232 and USB
Display .....	Monochrome LCD, °C or °F user-selectable
Display Resolution .....	0.1 °C or °F
Size (H x W x L) .....	400 mm x 337 mm x 700 mm (15.7 in x 13.3 in x 27.6 in)
Net Weight.....	29 kg (63.9 lb) without isothermal block

### Isothermal Block (optional)

Block Construction .....	Alumina
Block Outer Diameter.....	37 mm (1.5 in)
Block Length .....	380 mm (15.0 in)
Well Diameter (four wells total)....	6.7 mm (0.26 in)
Well Depth.....	365 mm (14.4 in)
Net Weight.....	0.84 kg (1.9 lb) isothermal block only

## Accuracy specifications

All accuracy specifications except temperature are for a period of 1 year after calibration, at 13 °C to 33 °C.

The furnace can be used with or without an Isothermal Block installed. Unique calibration parameters are necessary for each configuration. Calibration does NOT come standard from the factory for each configuration. Ensure that the furnace has been properly calibrated for the desired mode of operation.

Furnace Temperature Range ..	300 °C to 1200 °C
Set-Point Accuracy .....	± 5 °C

### Radial Uniformity

Temperature	9118A (14 mm (0.6 in) from geometry central point)	9118A-ITB hole-to-hole
300 °C	± 0.5 °C	± 0.1 °C
700 °C	± 0.5 °C	± 0.20 °C
1200 °C	± 0.5 °C	± 0.25 °C

### Axial Uniformity

Temperature	9118A (± 30 mm (1.2 in) axial length from geometry central point)	9118A-ITB (at 60 mm (2.4 in) from full immersion)
Full Range	± 0.25 °C	± 0.2 °C

### Temperature Stability

Specification	9118A	9118A-ITB
Stability	± 0.2 °C	± 0.1 °C
Stabilization Time	2 hours, full range	3 hours at or below 700 °C, 2 hours above 700 °C

**Note:** Temperature stability measured as 2-sigma over 30 minutes

### Heating Time (23 °C to 1200 °C)

9118A .....	40 minutes
9118A-ITB.....	45 minutes

### Cooling Time (1200 °C to 300 °C)

9118A .....	180 minutes
9118A-ITB.....	200 minutes

## Ordering Information

### Models

9118A .....	9118A Thermocouple Calibration Furnace without Isothermal Block
9118A-ITB .....	9118A Thermocouple Calibration Furnace with Isothermal Block

### Accessories

9118A-3118-1 .....	9118A Isothermal Block, 6.35 mm (0.25 in) wells x 4
--------------------	--

**Fluke Calibration.** Precision, performance, confidence.™

Electrical	RF	Temperature	Pressure	Flow	Software
------------	----	-------------	----------	------	----------

**Fluke Calibration**  
PO Box 9090, Everett, WA 98206 U.S.A.  
**Fluke Europe B.V.**  
PO Box 1186, 5602 BD  
Eindhoven, The Netherlands

**For more information call:**  
In the U.S.A. (877) 355-3225 or  
Fax (425) 446-5116  
In Europe/M-East/Africa +31 (0) 40  
2675 200 or Fax +31 (0) 40 2675 222  
In Canada (800)-36-FLUKE or  
Fax (905) 890-6866

From other countries +1 (425) 446-5500 or  
Fax +1 (425) 446-5116  
Web access: <http://www.flukecal.com>

©2014 Fluke Calibration.  
Specifications subject to change without notice.  
Printed in U.S.A. 7/2014 6002181b-en  
Pub-ID 13058-eng