

	<u>fixq</u>		<u>uut_ind</u>	<u>lower_limit</u>	<u>upper_limit</u>	<u>test_status</u>
Fluke 23: (1 year) CAL VER /5520						
100.0 Ohm	100.00	Ohm	99.9	99.3	100.7	Pass
100.0 Ohm	100.00	Ohm	100.0	99.3	100.7	Pass
100.0 Ohm	100.00	Ohm	100.0	99.3	100.7	Pass
1000 Ohm	1000.0	Ohm	1000	994	1006	Pass
1000 Ohm	1000.0	Ohm	1001	994	1006	Pass
1000 Ohm	1000.0	Ohm	1000	994	1006	Pass
10.00 kOhm	10.000k	Ohm	10.00	9.94	10.06	Pass
10.00 kOhm	10.000k	Ohm	10.01	9.94	10.06	Pass
10.00 kOhm	10.000k	Ohm	10.00	9.94	10.06	Pass
100.0 kOhm	100.00k	Ohm	100.0	99.4	100.6	Pass
100.0 kOhm	100.00k	Ohm	100.1	99.4	100.6	Pass
100.0 kOhm	100.00k	Ohm	100.0	99.4	100.6	Pass
1.000 MOhm	1.0000M	Ohm	1.000	0.994	1.006	Pass
1.000 MOhm	1.0000M	Ohm	1.001	0.994	1.006	Pass
1.000 MOhm	1.0000M	Ohm	1.000	0.994	1.006	Pass
10.00 MOhm	10.000M	Ohm	10.02	9.79	10.21	Pass
10.00 MOhm	10.000M	Ohm	10.00	9.79	10.21	Pass
10.00 MOhm	10.000M	Ohm	10.01	9.79	10.21	Pass
10.00 MOhm	10.000M	Ohm	10.01	9.79	10.21	Pass
300.0 mV	300.00m	V	299.9	299.0	301.0	Pass
300.0 mV	300.00m	V	299.8	299.0	301.0	Pass
300.0 mV	300.00m	V	299.7	299.0	301.0	Pass
300.0 mV	300.00m	V	299.5	299.0	301.0	Pass
300.0 mV	300.00m	V	300.1	299.0	301.0	Pass
2.700 V	2.7000	V	2.699	2.691	2.709	Pass
2.700 V	2.7000	V	2.700	2.691	2.709	Pass
2.700 V	2.7000	V	2.697	2.691	2.709	Pass
2.700 V	2.7000	V	2.701	2.691	2.709	Pass
27.00 V	27.000	V	27.01	26.91	27.09	Pass
27.00 V	27.000	V	27.00	26.91	27.09	Pass
27.00 V	27.000	V	26.99	26.91	27.09	Pass
27.00 V	27.000	V	26.98	26.91	27.09	Pass
27.00 V	27.000	V	27.01	26.91	27.09	Pass
270.0 V	270.00	V	270.0	269.1	270.9	Pass
270.0 V	270.00	V	270.1	269.1	270.9	Pass
270.0 V	270.00	V	269.9	269.1	270.9	Pass
270.0 V	270.00	V	269.8	269.1	270.9	Pass
270.0 V	270.00	V	270.2	269.1	270.9	Pass
1000 V	1000.0	V	1002	995	1005	Pass
1000 V	1000.0	V	1001	995	1005	Pass
1000 V	1000.0	V	1001	995	1005	Pass
2.700 V @ 100 Hz	2.7000	V	2.703	2.644	2.756	Pass
2.700 V @ 100 Hz	2.7000	V	2.704	2.644	2.756	Pass
2.700 V @ 100 Hz	2.7000	V	2.707	2.644	2.756	Pass
2.700 V @ 100 Hz	2.7000	V	2.702	2.644	2.756	Pass
2.700 V @ 100 Hz	2.7000	V	2.701	2.644	2.756	Pass
2.700 V @ 100 Hz	2.7000	V	2.698	2.644	2.756	Pass

		<u>fixq</u>	<u>uut_ind</u>	<u>lower_limit</u>	<u>upper_limit</u>	<u>test_status</u>
2.700 V @ 100 Hz	2.7000	V	2.701	2.644	2.756	Pass
2.700 V @ 500 Hz	2.7000	V	2.693	2.644	2.756	Pass
2.700 V @ 500 Hz	2.7000	V	2.692	2.644	2.756	Pass
2.700 V @ 500 Hz	2.7000	V	2.695	2.644	2.756	Pass
2.700 V @ 500 Hz	2.7000	V	2.689	2.644	2.756	Pass
2.700 V @ 500 Hz	2.7000	V	2.690	2.644	2.756	Pass
2.700 V @ 500 Hz	2.7000	V	2.691	2.644	2.756	Pass
2.700 V @ 500 Hz	2.7000	V	2.686	2.644	2.756	Pass
2.700 V @ 500 Hz	2.7000	V	2.689	2.644	2.756	Pass
750 V @ 100 Hz	750.0	V	751	733	767	Pass
750 V @ 100 Hz	750.0	V	752	733	767	Pass
750 V @ 100 Hz	750.0	V	750	733	767	Pass
750 V @ 100 Hz	750.0	V	750	733	767	Pass
750 V @ 1000 Hz	750.0	V	753	733	767	Pass
750 V @ 1000 Hz	750.0	V	754	733	767	Pass
750 V @ 1000 Hz	750.0	V	751	733	767	Pass
27.00 mA	27.000m A		26.88	26.57	27.43	Pass
27.00 mA	27.000m A		26.98	26.57	27.43	Pass
27.00 mA	27.000m A		27.05	26.57	27.43	Pass
27.00 mA	27.000m A		26.95	26.57	27.43	Pass
27.00 mA	27.000m A		26.90	26.57	27.43	Pass
27.00 mA	27.000m A		26.96	26.57	27.43	Pass
27.00 mA	27.000m A		27.08	26.57	27.43	Pass
27.00 mA	27.000m A		26.90	26.57	27.43	Pass
200.0 mA	200.00m A		199.7	195.8	204.2	Pass
200.0 mA	200.00m A		199.9	195.8	204.2	Pass
200.0 mA	200.00m A		200.6	195.8	204.2	Pass
200.0 mA	200.00m A		199.6	195.8	204.2	Pass
200.0 mA	200.00m A		200.1	195.8	204.2	Pass
200.0 mA	200.00m A		199.8	195.8	204.2	Pass
200.0 mA	200.00m A		199.0	195.8	204.2	Pass
200.0 mA	200.00m A		201.2	195.8	204.2	Pass
200.0 mA	200.00m A		199.4	195.8	204.2	Pass
2.00 A	2.000 A		1.98	1.94	2.06	Pass
2.00 A	2.000 A		1.99	1.94	2.06	Pass
2.00 A	2.000 A		2.00	1.94	2.06	Pass
2.00 A	2.000 A		2.01	1.94	2.06	Pass
2.00 A	2.000 A		1.99	1.94	2.06	Pass
2.00 A	2.000 A		1.98	1.94	2.06	Pass